



BROBO GROUP®

A.C.N. 098 264 316
A.B.N. 42 098 264 316

BROBO GROUP (AUST) PTY. LTD.

8 Fowler Rd, Dandenong South
Victoria 3175, AUSTRALIA.

+ 61 3 9794 8751

+ 61 3 9794 8792

info@brobo.com.au

www.brobo.com.au



PRODUCT & MAINTENANCE MANUAL

MANUAL NON-FERROUS UPCUT

MODEL No: TNF125



YOUR BROBO DISTRIBUTOR IS:

- Precision Drilling Machines • Tapping Machines • Multi Head Drills • Tool Grinders •
- Tool Post Grinders • Machine Vices • Special Production Equipment •
- Accessories • Riveting Machines • Pedestal Grinders • Metal Cutting Saws • Linishers •

OPERATING MANUAL FOR BROBO GROUP MANUAL NON-FERROUS UPCUT SAW

TECHNICAL SPECIFICATION

CHAPTER 1: Installation of the Machine

- 1.1 Unpacking & Handling the Machine
- 1.2 Parts Checklist
- 1.3 Minimum Requirements
- 1.4 Working Area Requirement
- 1.5 Connection to Power Source

CHAPTER 2: Safety & Accident Prevention

- 2.1 Operation of the Machine
 - 2.1.1. Noise Level
 - 2.1.2. Power Supply
 - 2.1.3. Compressed Air Supply
- 2.2 General Requirements
- 2.3 Advice for the Operator
- 2.4 Machine Safety Devices
 - 2.4.1. Reference Standards

CHAPTER 3: Main Functions & Operation of the Machine

- 3.1 Main Features
 - 3.1.1. Saw Safety Guard
 - 3.1.2. Pneumatic Vice Clamp
 - 3.1.3. Up Cut Saw
- 3.2 Preparation for Operation
- 3.3 Operation Recommendations

CHAPTER 4: Drawings, Layouts, Assembly & Spare Parts

CHAPTER 5: Maintenance & Selection of Consumables

- 5.1 Role of the Operator
- 5.2 Maintenance Requirements
- 5.3 General Maintenance of Functioning Components
- 5.4 Brobolube Unit

CHAPTER 6: Troubleshoot

- 6.1 Troubleshooting For Blade & Cutting Problems

APPENDIX

- i. Workplace Health & Safety Policy

TECHNICAL SPECIFICATION

SPECIFICATIONS

Voltage:	380 - 460	V
Frequency:	50/60	Hz
Motor power:	1.5	kW
Motor speed:	2810	rpm
Total power:	1.5	kW
Air pressure:	6–8	Bar
Air consumption:	41	l/min
Saw blade external Ø diameter:	450	mm
Saw blade internal Ø diameter:	30	mm
Saw blade thickness:	4	mm
Saw blade Z:	120	tooth
Saw blade speed:	3200	rpm
Minimum cutting length:	440	mm
Maximum cutting length:	3300	mm
Cutting angle range:	45° - 90°	
Minimum cutting width:	148	mm
Width:	900	mm
Length:	850 (6900)	mm
Height:	1250	mm
Weight:	150	kg

STANDARD FEATURES

- Mitering 90° left, straight 90° and 90° right with rapid adjustment bumpers
- Adjustable cutting speed
- Vertical pneumatic clamping
- Fully enclosed lid/guard with protective power supply shut down
- Power source protects against abrupt changes in voltage
- Saw exit speed regulator brings down speed in aluminium cutting, thus enables decreasing engine load
- Ø 450mm TCT Blade
- Two feed roller conveyors (3m long each)
- 3m Adjustable length stop

CUTTING RANGE

CHAPTER 1 - Installation of the Machine

1.1. Unpacking & Handling the Machine



WARNING – HEAD HEAVY MACHINES

The metal sawing machines are heaviest where the saw heads are fitted & as such, care must be taken while relocating or moving the machines.

Upon receiving the **Brobo Group TNF125 Upcut Saw**, the machine should be standing upright & positioned centrally on top of a wooden pallet. While the machine is situated on the pallet, position the forklift arms under the pallet between the runners, keeping in mind that the machine is **head heavy**. Move the entire unit to an accessible area as close as possible to the final location.

Carefully remove the wooden frame surrounding the saw unit (Figure 1). Once completed, proceed by elevating the machine away from the pallet base using a sling harness wrapped around the cutting head of the saw. Ensure that the floor is as level as possible before finally positioning the machine to the desired location.



FIGURE 1. Handling of TNF125 Upcut Saw

PLEASE OBSERVE & FOLLOW THE INSTALLATION INSTRUCTIONS ON PAGE 7

1.2. Parts Checklist

Along with the saw unit, check that the following accessories, packed "loose", are included as follows:

STANDARD ACCESSORIES

- | | |
|----------------------------------|----|
| 1. Saw Blade | x1 |
| 2. TNF Conveyor | x1 |
| 3. TNF Conveyor with Length Stop | x1 |
| 4. TNF Stand | x2 |
| 5. Mounting Brackets | x2 |
| 6. Light Duty Air Vice | x2 |



1.3. Minimum Requirements

For the machine to function correctly, the room in which the saw unit is to be installed must be in the vicinity of, & satisfy the following conditions:

- 240/415V Power Supply
- Working Pressure - Not less than 600kPa (6 Bar) & no greater than 900kPa (9 Bar)
- Ambient Temperature - From -10 °C to +50 °C.
- Relative Humidity: Not more than 90%.
- Lighting: More than 500 LUX.



WARNING – OPERATING VOLTAGE VARIATION

Each saw model has an inbuilt safety system to protect it against voltage variations. However, for the machine to perform efficiently, ensure that the saw unit operates within $\pm 10\%$ limits of the recommended voltage of the motor.

1.4. Working Area Requirement

Ensure safe work area away from clutter, combustible materials, sufficient lighting. The saw to be secured on firm weight bearing surface. Floor to be level and with non-slip properties.




Figure 2. Working Area Requirement

1.5. Connection to Power Source

Before connecting the machine to the power supply, check that the socket is not connected in series with other machines. This condition is critical for the ideal operation of the saw unit.

Single & Three Phase

- a) **Single phase machines** are provided with three pins, **15 amps** rated plugs & leads for connection to **240V**, **50Hz** power supply in **Australia**.




Figure 3.1 Connection 3 pins – 1 Phase

- b) **Three phase machines**




Figure 3.2 Connection for “5-CORE” Wire System with Neutral – 3 Phase

- c) Check the power supplied & motor specifications before plugging in the machine. Check the terminal connection on dual voltage motor terminal box & connect it accordingly to the corresponding voltage supply.
- d) If the dual motor is requested, the motor is **always** connected to the higher voltage, unless otherwise specified prior to the order being placed.

To connect the machine to the power supply, proceed as follows:

- 1) Insert the power plug into the socket, while ensuring that the **mains voltage is compatible** for which the saw unit is operating at.
- 2) Switch the saw on
- 3) Make sure that the saw is NOT currently in an emergency condition, whereby the **EMERGENCY STOP** button is depressed. If so, twist the red mushroom button until it is released & returned to the neutral state.
- 4) Ensure that all electrical leads & cables (including supply leads) are maintained in a good condition & away from sharp objects. All leads should be replaced if cut, sliced or damaged in any way.

CHAPTER 2 - Safety & Accident Prevention

The **Brobo Group TNF125 Upcut Saw** has been designed & manufactured in accordance with **Australian Standards**. It is **HIGHLY RECOMMENDED** that the instructions & warnings contained in this chapter be carefully followed for correct usage of the machine.

2.1. Operation of the Machine

The **Brobo Group TNF125 Upcut Saw** is specifically designed to cut non-ferrous metal cross sections with solid or thin-walled profiles. Other types of material & machining are not compatible for use with the specifications of the saw. ***This machine involves a high-speed blade rotation; therefore extreme caution is required when operating the device.***

The employer is responsible for instructing the personnel who, in turn, are obliged to inform the operator of any accident risks, safety devices, noise emission & accident prevention regulations provided for by national & international laws governing the use of the machine. ***The operator must be fully aware of the position & functions of all the machine's controls.***

All those concerned must strictly adhere to ALL instructions, warnings & accident prevention standards in this manual.

The following definitions are those provided for by the **EEC DIRECTIVE ON MACHINERY No. 98/37/CE**:

- **Danger Zone** - any zone in and/or around a machine in which the presence of a person constitutes a risk to the safety & health of that person.
- **Person Exposed** - any person finding him or herself, either completely or partly in a danger zone.
- **Operator** - the person or persons are given the responsibility of installing, operating, adjusting, maintaining, cleaning, repairing, & transporting the machine.



WARNING – UNAUTHORISED MODIFICATIONS/REPLACEMENTS/USE

The manufacturer declines any responsibility whatsoever, either civil or criminal, in the case of unauthorised interference or replacement of one or more parts or assemblies on the machine, or if accessories, tools & consumable materials used are different from those recommended by the manufacturer, or if the machine is inserted in a plant system & its proper function is altered.

2.1.1. Noise Level

The noise level of an idling saw has been measured to be **below 85 dBA**. This complies with the **Australian Occupational Health & Safety (Noise) Regulations 1992**.

Please note that peak impulse noise levels will be experienced due to variables including blade characteristics, type, & condition. This will also vary accordingly depending on the size & type of sample being cut. Under these circumstances, management should make available to the operator(s) the appropriate hearing protection equipment as prescribed under the above-stated act.

ALLUMINIUM	IN VACUM	
	Medium value of the sonorous level measured	Lmp= 75,1 dB (A)
	Value of the sonorous level in the working position measured	Lmp= 81,3 dB (A)
	Factor of environmental correction	K= 1 dB (A)
	Medium value of the correct sonorous level	Lpc= 74,1 dB (A)
	Value of sonorous level in the correct working position	Lpc= 80,3 dB (A)
	LOADED	
	Medium value of the sonorous level measured	Lmp= 86,3 dB (A)
	Value of the sonorous level in the working position measured	Lmp= 91,1 dB (A)
	Factor of environmental correction	K= 1 dB (A)
	Medium value of the correct sonorous level	Lpc= 85,3 dB (A)
	Value of sonorous level in the correct working position	Lpc= 90,1 dB (A)



2.1.2. Power Supply

The 415/240V power supply requirements for this machine are of a high level & unauthorized interference and or inadequate maintenance could result in a situation that could put the operator at risk. A **qualified** electrical engineer should always be assigned to maintain & repair the system.

International Protection Rating code (Ingress Protection): **IP54**

First Digit: Solid - Level 5:

Protected from limited dust ingress.

Second Digit: Liquid – Level 4:

Protected from water spray from any direction.



2.1.3. Compressed Air Supply

Various functions of the saw are carried out via the use of 6 bar compressed air. During these operations, situations would arise where machine parts & materials are clamped together & would potentially pose a serious safety issue to an inexperienced operator. Operators should be thoroughly instructed about these hazards.

Only a qualified electrician should carry out regular maintenance of this system.

2.2. General Requirements

Lighting

Insufficient lighting during the operation of the saw unit would constitute a safety hazard for the people concerned. For this reason, the user of the machine must provide adequate lighting in the working area to eliminate areas of shadow, whilst also preventing dazzling illumination sources

(Reference standard **ISO 8995 - 2002 'Lighting of Indoor Workplaces'**).

Connection

Check that the power supply cables, compressed air supply (if applicable) & coolant system complies with, & are operating within the acceptable range of the saw capabilities.

Faulty, damaged or worn components must be replaced immediately.

Earthing Systems

The installation of the earthing system must comply with the requirements stated in the:

IEC Standards Part 195: Earthing & Protection Against Electric Shocks 1998.

2.3. Advice for the Operator



Protective eyewear or goggles must be worn at all times while attending & operating the metal saw.



Do not attempt to operate the machine unless all safety guards are in operation.
The guard must fully cover the blade when the head is in the uppermost position.



Ensure that **hands & arms are kept clear of the cutting zone** when the machine is operating.



Do not wear loose clothing with long sleeves & oversized gloves, bracelets, necklaces or any other loose object that may become entangled in the machine's blade during cutting. Long hair must be tied back or placed in a hair net.



Always disconnect the power supply to the machine before carrying out any maintenance work or adjustments. This includes cases of abnormal operations of the machine.



Any maintenance work performed on the hydraulic, pneumatic or coolant systems must be carried out only after the pressure in the system has been released.



The operator **MUST NOT** conduct any risky operations or those not required for the cutting in course (e.g. remove swarf shavings from the machine while cutting).
Never move the saw while the machine is operating.



Always keep the workplace as clean as possible.
Remove equipment, tools or any other objects from the cutting zone.



Support the workpiece on both sides of the machine to prevent it falling or jamming during the cutting cycle.



Ensure that the specimen being cut is secured firmly in the vice clamps & the machine has been correctly set. *Figure A* show some examples of how to correctly clamp different specimen profiles. Before commencing the cut, be sure the vice(s) is securely clamped & the machine set-up is correct.




Figure A. Correct Clamping of Cutting Specimens



Do not use cutting blades of different sizes to those recommended to the machine's specifications. Always follow safe practices & inspection procedures when installing blades



When cutting very small specimens, ***ensure that the workpiece is not dragged behind the back fence support***, where it could get lodged behind the blade.



If the blade jams during a cut, activate the emergency stop function immediately. Do not continue forcing the blade through. This could damage the blade, the specimen or be a cause for potential injury to the operator.



Always turn off the machine before carrying out any repair work. Consult the **Brobo Group** Engineering Department in the country in which the machine was initially purchased.

2.4. Machine Safety Devices

This product & maintenance manual is not purely intended as a guide for the usage, operation & maintenance of the saw unit in a strict production environment; it is instead an instrument to providing information on how to use the machine correctly & safely. The following standards listed in section 2.4.1, which are applicable to the **Brobo Group TNF125 Upcut Saw**, are those specified by the EEC Committee that governs the safety of machinery, health & safety at work, personal protection & safeguarding of the work environment. In addition, the saw also complies with the Australian Standards regarding the safeguarding & general requirements for electrical equipment.

2.4.1. Reference Standards



MACHINE SAFETY

- *EEC Directive No. 98/37/CE - Machines Directive*
- *EEC Directive No. 91/368 - 94/68 - Amends sections of EEC Directive No. 98/37/CE relating to machine safety*
- *EEC Directive No. 73/23 - Low Voltage Directive*
- *AS4024.1 - 1996 - Safeguarding of Machinery*

HEALTH & SAFETY AT WORK

- *AS3100 - 2002 - General Requirements for Electrical Equipment*
- *OH. & S. 1995.81/1995 - Compliance References*
- *EEC Directive No. 80/1107; 83/477; 86/188; 88/188; 88/642 - Protection of workers against risks caused by exposure to physical, chemical & biological agents in the workplace*
- *EEC Directive No. 73/23 & Special EEC Directives No. 89/654; 89/655 - Improvements in health & safety at work*

CHAPTER 3 - Main Functions & Operation of the Machine



Figure 4. Up Cut Saw Main Components

3.1. Main Features

3.1.1. Saw Safety Guard

The primary purpose of the saw safety guard is to protect the user from the spinning blade. It also functions as a safety device to protect the operator from any broken tooth, swarf or high-velocity particles that might be dislodged by the cutting process. During the use of the machine do not remove the guard & make sure that they are in correct working order.

3.1.2. Pneumatic Vice Clamp

Pneumatic vice Clamps use air-actuated cylinders to operate the clamping action. They are ideal for quick clamping in repetitive production operations, and yet are portable & economical to use on short run jobs with temporary fixturing. Clamp Switch to activate the clammer to secure the movement of the workpiece.

3.1.3. Up Cut Saw

The saw blade travels up and through the product. When the cut is completed, the saw blade returns to its down position.

3.2. Preparation for Operation

The following procedure is recommended for the correct cutting using the **Brobo Group TNF125 Upcut Saw**



WARNING – SAFETY GEAR

*Protective clothing, safety glasses and gloves should **always** be worn while loading parts, operating the machine, or undertaking any maintenance work on the saw.*

PROCEDURE

1. Cleaning

Using a non-flammable & toxic free solvent, clean the machine to remove any corrosion protective coating prior to use.

2. Power On

Ensure that both the air & electric power systems are turned on, where applicable. The electrical power source must be available before any pneumatic functions will operate.

3. E-Stop Button

Ensure that E-Stop Button is in the out, extended position. E-stops are not used to stop equipment for production problems that do not affect safety.

4. Clamp Switch

The product is placed on to rotary table horizontally. Press the clamp switch to secure the product.

5. Safety Guard

Close the safety guard

6. 2 Cut Buttons

Push and hold 2 cut button to start. This is one of the saw safety features to make sure that the saw can only be operated by 2 hands. Release the cut buttons to finish the cut. Press the clamp switch for the clamp to release the product.



WARNING - BLADE JAMMING

*If the saw blade jams during a cut, engage the **EMERGENCY STOP** immediately. Remove the part, check that the blade is not damage and if need be, replace the blade.*



WARNING - BLADE MOTOR OVERLOAD

Saw is equipped with overload monitoring system which detects main motor overload in case of blade jam or inadvertent misuse. In case of overload saw reverses feed, re-establishes correct running of motor & continues the cut. If the saw overload system is reversing feed regularly during a cut, it indicates the blade is worn. Replace the blade promptly at this occurrence changes.

3.3. Operation Recommendations


- Select the correct saw blade with the correct tooth pitch & form to suit the material to be cut to provide minimum burr & maximum blade lifespan.
- Use the smallest diameter blade & coarsest pitch that is practical within the required speed & material limitations.
- Generally, use a tooth pitch to give 2 - 4 teeth engagement with the material during cutting.
- Ensure that sufficient coolant is flowing over the cutting teeth.
- The rate of feed affects the quality of the final cut & blade life. This varies also by the material & cross-sectional dimensions.
- As a rule of thumb ***the softer the component, the faster the rate of speed***. Thus, it is recommended that slower speeds be used for hard & tough materials & higher speeds for soft, ductile materials. Note that for non-ferrous materials such as brass, copper, aluminium etc. require much faster speeds than Ferrous Metal Cutting Saw.

CHAPTER 4 - Drawings, Layouts, Assembly & Spare Parts

MAGNETIC SENSOR

- ▶ There is a magnet inside the pneumatic cylinder and this magnet moves with the piston.
- ▶ The magnetic sensor connected to the surface of the piston open its contacts when it is effects by this magnet. If the position of the magnetic sensor changes that is to say it will not contact with the magnet so the signal will not go the PLC and therefore there will not be any action performed.

In this case the sensor is placed by moving forward or backward slightly in the arrow direction. (the light on the sensor turns on when the magnet contacts with the sensor and the sensor is fixed in that position so the problem will be solved).




1. Sensor
2. Piston and magnet

CHANGING THE BLADE


1. All air and electrical connections should be disconnected.
2. Protective covers must be removed.
3. The nuts on the motor spindle where the saw is installed are must be removed from the saw place by opening in the opposite direction to each others.
4. After the saw is replaced with the new one, the same procedure is reversed.
5. After the saw is replaced the covers are replaced too.



Wear gloves during the saw replacement.




VALVE AND CYLINDER CONTROL



1. Piston cuff
2. Ring gasket

- If some operations on machine does not start to process or an air leakage occurs continuously in the valves, you should perform following:
 1. Look the pneumatic drawing to understand which cylinder works with which valve. If you don't have the pneumatic drawing, follow the input- output pipes of the cylinder to understand.
 2. Take off the air pipes connected to the A and B cable glands. Give air from A and check from B. If air comes from B, the cylinder seal must be malfunctioning.
 3. When air is given from B, the cylinder rod must still be giving out air, the neck seal C must be malfunctioning. If after checking them, A, B and C give out no air but there still is a leakage through the valves exhaust, check the valve.
 4. After you have checked them, if A, B and C give out no air but there still is a leakage through the valves exhaust, then check the valve.
 5. If the coil does not move by pressing the manual button, the coil may have broken down and it must be replaced. (A very low voice coming from coils when electric applied to them must be heard.) If the voice cannot be heard, check the electricity feed for coils.

CYLINDER SPEED ADJUSTMENT



- ▶ The part adjustment nut numbered (1) is loosened. The adjustment bolt numbered (2) is fastened or loosened.
- ▶ Therefore the piston motor movement enabling speed is detected by adjusting the pressure affecting the piston (6) inside the cylinder (5). Also by loosening and opening the screw numbered (3) we can make the adjustment of padding.


NOTE: This process is applied in the same way for every cylinder with air reducer.

NOTE: It is used to prevent the shaking or the bumping in the last point of the direction in the opening or closing of the piston spindle.

HYDRAULIC SPEED CONTROL CYLINDER

(option for aluminium profiles cutting)

- The hydraulic speed control check normally couples with a pneumatic cylinder to provide uniform speed control.




1. Speed control regulator
2. Reserve tank
3. Cylinder

- Speed control is adjustable by (1) regulator.

COOLING SYSTEM

(option for aluminium profiles cutting)



1. Coolant Spray speed regulator
2. Coolant tank
3. Pneumatic cylinder
4. Hydraulic speed control cylinder

- ▶ Cutting fluids are various fluids that are used in machining to cool and lubricate the cutting tool.



Before PVC profiles cutting operation started switch OFF the cooling system. Open the protective covers of cutting heads and clean the inside area from coolant.


- ▶ **Cutting fluid recommended to use:**

«Brobolube

FILTER-REGULATOR



The first condition for a pneumatic system to function properly is to supply enough and quality pressured air.



1. Pressure regulator
2. Air pressure manometer
3. Condensate unit
4. Nipple for condensate discharging
5. Regulating screw for oil feeding
6. Oil unit

► Filter cleans the compressed air of impurities, rust, pipe deposits and condensation.

SETTING INSTRUCTIONS

Pressure Adjustment: Regulator head shown with 1 is pulled up. If it is turned on in the clockwise direction lubricators' outlet air pressure will increase. If turned in counter clockwise direction, the pressure will decrease.

Condensate discharging: The emptying screw shown with number 4 is opened and the condensate liquid will discharge.


Oil filling: Oil unit shown with number 6 is pulled off by turning it on clockwise direction. Then pneumatic oil is added to the container.

Oil speed adjustment: If the adjustment screw shown by number 5 is turned in the clockwise direction, the oil speed will decrease if screw is turned in the opposite direction, it starts giving oil faster to the system. Oil output should be as **one drop / minute** at air feeding.

RECOMMENDED FILTER-REGULATOR OILS



1. ESSO NUTO H32
2. MOBIL DTE24SHELL TELLUS C10
3. SHELL TELLUS C10
4. FESTO SPECIAL OIL
5. PETROL OFISI SPINDURA 10
6. ARAL VITAM GF32
7. MOBIL DHE LIGHT




38	DNC-50-160-PPV-A 2	PISTON	1
37	DNC-50-160-PPV-A 1	CYLINDER	1
36	11.404.014	BEARING COVER	1
35	11.404.013	SAW REAR FLANGE	1
34	11.404.012	SAW FRONT FLANGE	1
33	SKF - 6206 - 12,DE,NC,12_68	BALL BEARING	1
32	11.404.010	SAW CLAMP	1
31	11.404.008	SPINDLE	1
30	11.404.007	Ø60 A13x1 PULLEY	1
29	SKF - 6008 - 16,DE,NC,16_68	BALL BEARING	1
28	10.000.039	SAW NUT	1
27	MOTOR-AYAKSIZ VM 80-B14 1-5 KW	MOTOR	1
26	LME 25 UU	BEARING HOUSE	4
25	M12 x 70	SCREW	1
24	TESTERE	Ø85 A13x1 MOTOR PULLEY	1
23	11.404.006		1
22	11.404.004	1-5 KW MOTOR PLATE	1
21	11.404.003	SHAFT	1
20	11.404.002	MOVING BODY	1
19	11.404.001	PIN	1
18	50 LİK PISTON MAFSAL	PISTON	1
17	11.403.004	SAW LOCK	1
16	11.403.003	PISTON LOCK	1
15	11.403.002	PIN	2
14	11.403.001	ROTARY TABLE	1
13	Dişi ELCİK M8	KNOB	1
12	10.000.085	FLANGE	1
11	10.000.084	PIN	1
10	11.402.002	NUT	1
9	10.000.089	CLAMP PLATE	1
8	11.402.014	BLOCK	1
7	11.403.007	ARROW	1
6	11.402.003	ALUMINIUM pLATE	1
5	11.402.007	BACK FENCE	1
4	10.000.088	CLACLAMPING TABLE	1
3	50 LİK PISTON AYAK	PISTON PLATE	1
2	ROD_M16_DISI	ROD	1
1	ROD_M16_KURE	SPHERE	1
NO	PART NAME	NAME	QTY



BROBO GROUP® A.C.N. 098 264 316
A.B.N. 42 098 264 316
BROBO WALDOWN (AUST) PTY. LTD.
8 Fowler Rd, Dandenong South, 3175
Victoria, AUSTRALIA.
Tel: 61 3 9794 8751
Fax: 61 3 9794 8792
Email: info@brobo.com.au
Website: www.brobo.com.au






ÖĞE NO.	PARÇA NUMARASI	PARÇA ADI	MİKT.
1	12.701.001	FRAME	1
2	12.701.002	SIDE COVER 1	2
3	12.701.003	BACK COVER 2	1
4	ÇEK VALF (135)	VALVE	2
5	HIZ AYAR VALFI	ADJ VALVE	1
6	SOĞUTMA DEPO bidonu (135)	TANK	1
7	ŞARTLANDIRICI-2	VALVE	1
8	MAKTAŞY.	BASE	1
9	KUMANDA PANOSU	LABEL	1
10	BUTON YEŞİL-KIRMIZI (135)	START STOP	2
11	BUTON ACIL STOP (135)	E-STOP BUTTON	1
12	BUTON YESİL (135)	START BUTTON	2
13	hava tab-1	AIR GUN	1



BROBO GROUP
BROBO WALDOWN (AUST) PTY. LTD.
 8 Fowler Rd, Dandenong South, 3175
 Victoria, AUSTRALIA.
 Tel: 61 3 9794 8751
 Fax: 61 3 9794 8792
 Email: info@brobo.com.au
 Website: www.brobo.com.au

A.C.N. 098 264 316
 A.B.N. 42 098 264 316







BROBO GROUP®
BROBO WALDOWN (AUST) PTY. LTD.
 8 Fowler Rd, Dandenong South, 3175
 Victoria, AUSTRALIA.
 Tel: 61 3 9794 8751
 Fax: 61 3 9794 8792

A.C.N. 098 264 316
 A.B.N. 42 098 264 316

Email: info@brobo.com.au
 Website: www.brobo.com.au



ITEM NO.	PART NO.	DESCRIPTION	QTY	DESCRIPTION	PART NO.	DESCRIPTION	QTY
1	11.702.004	CLAMPING TABLE	1	35	HINGE01	HINGE	1
2	11.702.007	SİPER	1	36	HINGE02	HINGE	1
3	11.702.003 α	BACK FENCE	2	37	11.702.019	GLASS	1
4	10.000.089	CENTRAL PIN	1	38	DESPA STP 18-08-235 SİLİNDİR	GAS SPRING	2
				39	DESPA STP 18-08-235 PİSTON	-	2
5	11.702.002	HEX NUT M20X1,5	1	40	AMORTİSÖR BAŞLIK 5 A	-	4
6	11.702.006	SHAFT	1	41	10.000.030	MOTOR BLOCK	1
7	M8 UFAK ELCİK	NUT M8	1	42	10.000.031	SHAFT	1
8	10.000.084	CENTER PIN	1	43	135.LK.01	BODY	1
9	11.702.015	SHAFT SUPPORT	2	44	10.000.034	FONT FLANGE	1
10	11.702.008	UPPER CONNECTION	1	45	10.000.035	REAR FLANGE	1
11	135.702.008	-	2	46	10.000.039	FLANGE	1
12	135.702.009	MESH	1	47	10.000.043	UT PULLEY	1
13	135.702.010	PROTECTION	1	48	10.000.006	BLOCK	1
14	11.702.011	ROD	2	49	SKF - 6206 - 12,DE,NC,12_68	BEARING	
15	135-09-007	HEX	2	50	SKF - 6008 - 16,DE,NC,16_68	BEARING	
16	TUTAMAK YILDIZ (135)	KNOB	2	51	TESTERE Ø450	SAW BLADE	1
17	00.000.002	PISTON PART	1	52	11.708.001	ARM	1
18	00.000.001	PISTON PART	1	53	GAZ YAĞLI Soğutma SİS.VALF	GAS OIL	1
19	00.000.004	PISTON PART	1	54	125B.LK.01	PLATE	1
20	00.000.015	WASHER	2	55	VM 90-B14 1-5 kW MOTOR-AYAKSIZ	MOTOR	1
21	00.000.029	CLAMP	3	56	11.703.001	ROTARY TABLE	1
22	00.000.016	PISTON	1	57	11.703.002	GUIDE ROD	2
23	00.000.017	PIN	1	58	11.703.003	PLATE	1
24	M10 SIKMA KOLU	HANDLE	2	59	DNC-50-180-PPV-A2	CYLINDER	1
25	11.704.020	SWITCH	2	60	DNC-50-180-PP-A-1	ROD	1
26	11.704.022	-	2	61	HC.40-200.001		1
27	11.702.040	CONNECTOR	2	62	HC.40-200.002	ROD	1
28	10.000.157	BLOCK	1	63	HC.008	CAP	1
29	M10 UFAK ELCİK	SCREW	1	64	socket countersunk head screw_am	SCREW	1
30	10.000.156	NUT	1	65	ISO 7434 - M8 x 10-C		
31	11.702.030	PIN	2	66	125 SWİCH	SWITCH	1
32	ön sac kapak-01	FRONT COVER	1	 BROBO GROUP® BROBO WALDOWN (AUST) PTY. LTD. <small>8 Fowler Rd, Dandenong South, 3175 Victoria, AUSTRALIA Tel: 61 3 9794 8751 Fax: 61 3 9794 8792</small> <small>Email: info@brobo.com.au Website: www.brobo.com.au</small>			
33	11.702.017		2				
34	135-TUTAMAK KOLU 8 LİK	ARM	1				



ITEM NO.	PART NO.	DESCRIPTION	QTY
1	10.000.007	FOOT CONNECTION	2
2	10.000.052	GUIDE BAR	2
3	10.000.053	SLIDE	1
4	10.000.054	LENGTH STOP	1
5	00.000.045	BOLT	1
6	10.000.051	GUIDE BAR	2
7	00.000.042	ROLLER	20
8	10.000.097	SHAFT	20
9	RULMAN 608 ZZ	BEARING	40
10	10.000.0050	MOUTING BRACKET	2
11	10.000.158	SCREW S	1
12	10.000.159	-	1
13	10.000.064	ROD	4
14	Hexagon Nut ISO - 4034 - M16 - S	M16 NUT	8
15	10.0000.0005	STAND	2




BROBO GROUP®
BROBO WALDOWN (AUST) PTY. LTD.
 8 Fowler Rd, Dandenong South, 3175
 Victoria, AUSTRALIA.
 Tel: 61 3 9794 8751
 Fax: 61 3 9794 8792


Email: info@brobo.com.au
 Website: www.brobo.com.au

A.C.N. 098 264 316
 A.B.N. 42 098 264 316



ELECTRIC CIRCUIT DIAGRAM





CHAPTER 5 – Maintenance & Selection of Consumables

5.1. Role of the Operator

The person operating & maintaining the **Brobo Group TNF125 Upcut Saw** must familiarise themselves with these instructions for their own safety & that of the others, in addition to safeguarding the production of the machine. Responsibility must be taken by the user on the general maintenance & up keeping of the unit as specified in this chapter, with particular emphasis on:

- Check to ensure that other operators of the machine always aware of and comply with the relevant safety instructions & standards as specified in *Chapter 2 - Safety & Accident Prevention*. Therefore, check that the safety devices are operational & work perfectly and that personal safety requirement is complied with.
- Ensure that the working cycle is efficient & guarantees maximum productivity, inspect the:
 - Functions of the main components of the machine
 - The sharpness of the blade & coolant flow
 - Correct working parameters for the type of material being cut
- Verify that the quality of the cut meets the requirements & the final product is free from any machining defects.

5.2. Maintenance Requirements

- All maintenance must be carried out with the power switched off & the machine in emergency stop condition.
- To guarantee for optimum operation, all spare parts must be **Brobo Group** originals.
- On completion of maintenance works, ensure that the replaced parts or any tools used have been removed from the machines before starting it up.
- Any behavior not in accordance with the instructions for using the machine specified in this manual may create hazards and/or safety risks for the operator.
- Therefore, read & follow all the instructions for use & maintenance of the machine, and those on the product itself.

5.3. General Maintenance of Functioning Components

The general maintenance operations that should be carried out regularly are as follows:

- 1) Keep the vice clamps, overall machine & path of the cutting blade free of any offcuts, accumulated swarf & coolant using compressed air or preferably thread-free cloth.
- 2) Change coolant as required, or whenever the coolant starts to get dirty or emits a stale odour. The coolant compensation tank should be checked regularly. Coolant level would expect to naturally decrease over time due to natural evaporation. Use premium quality coolants such as CoolTech 500 or SlideTech 68. Coolant is available from **BROBO GROUP** Pty. Ltd. in 2 litre & 20 litre packs (Part No. **9301570** & **9501080**): Concentrate, Ratio 1:20
- 3) Lubricate the rotary table regularly (after every 40 hours of operation, or weekly) with an NLGI 2 extreme pressure grease, Shell Alvania No.1 grease or equivalent.

- 4) Clean the vice & lubricate any moving joints or sliding surfaces with good quality oil.
- 5) Clean the machine regularly & keep any unpainted surfaces lightly oiled to protect from rust & corrosion.
- 6) The air supply for the pneumatic air vices should be checked regularly such that it is free of any condensed water molecules & the filter should be drained frequently.
- 7) Ensure that the machine performs cuts perpendicular to the work surface.
If not, contact **Brobo Group** engineering department.

5.4. Brobolube Unit

When assembled, the Brobolube unit is a precise instrument that supplies an accurate quantity of lubricant directly to the saw blade before it contacts the workpiece.

Although the lubricator is capable of delivering a much higher flow rate of lubricant, it is suggested that you do not increase the flow rate excessively because:

- No significant increase in blade life or lubricating efficiency will be achieved (confirmed by test results).
- Excessive application of **Brobolube** will only result in a waste of fluid.
- The excessive application will produce swarf that will be wet (oily) & harder to clean up than dry swarf produced from the correct supply of **Brobolube**.

5.4.1. Lubricating Oil Precautions - Health Hazard Information

The **Brobolube** lubricating fluid has no known adverse health effects. "**Brobolube**" is non-toxic, odourless, non-flammable below approximately 350°C, & non-corrosive, although it may affect some types of rubber. There are no traces of sulphur, chlorine, phenol or nitrates found in **Brobolube**. When comes into contact with skin, the oil may be removed by wiping away the excess, then washing the contaminated area with detergent & water. If the oil is utilized at high temperatures, appropriate protective apparel should be worn as the oil could cause burns to skin or eyes. If splashed by hot oil, immediately run cold water over the burn area & apply first aid burn treatment.

If the **Brobolube** delivery line breaks or becomes disconnected during operation, ensure that the air supply to the system is disconnected before repairing the problem.

It is recommended that footwear with anti-slip soles be worn at all times. Any spills will result in potentially hazardous slippery surfaces & should be dealt with promptly to prevent physical injury resulting from falls. Do not use coarsely, combustible material like sawdust to soak up oil due to the potential risk of spontaneous combustion. Spilled oil should be transferred into non-porous containers of suitable strength. Any remaining oil should be cleaned up with sand or other non-combustible, absorbent material. Place the sand and oil mixture into containers & disposed of by an EPA approved landfill or alternatively, by a suitable non-polluting method.



In addition, rags soaked in oil should not be burned. **Do not pour oil down the drain**, which would ultimately contaminate the water supply & pollute the environment.



For firefighting purposes, either use CO₂, dry chemical or foam retardant to extinguish the flames.



CHAPTER 6 - Troubleshoot

6.1. Troubleshooting For Blade & Cutting Problems

<u>PROBLEM IDENTIFIED</u>	<u>DIAGNOSIS</u>	<u>SOLUTIONS</u>
Cuts produced are not at 90° and/or are not perpendicular 	Head speed too low or too high	Reduce or increase head speed respectively.
	Blade with worn teeth	Replace with a new blade.
	Blade not perpendicular to the work surface	Adjust the blade using the appropriate screws such that it is perpendicular to the work surface.
Frequent and/or excessive teeth breaking 	Broken teeth	Check the hardness of the material being cut corresponds to the capabilities of the blade.
	Incorrect lubricant/coolant fluid	Check the water & oil mixture; check that the holes and/or hose are not blocked; direct the nozzles correctly;
	Material too hard	Check the cutting speed, feed speed, blade type & parameters are correct for the particular application.
	Blade not worn incorrectly	With a new blade, it is necessary to start cutting at <i>half feeding speed</i> . After a normalizing period (cutting surface about 300cm ² for hard materials & 1000cm ² for softer materials), both cutting & feed speeds can be brought up to normal values.
	Blade with incorrect and/or excessive fine tooth pitch	As excessive pressure is exerted on the incorrect teeth profile, replace the blade with correct tooth pitch dimensions & profile.

<p>Rapid teeth wear</p> 	Workpiece not clamped firmly in place	Any movement of the workpiece during the cutting process can cause broken teeth; check the vice clamps, clamping jaws & clamping pressure is satisfactory.
	Excessive vibrations	Specimen vibrates in the vice; check that the vice clamps are position correctly & the clamping pressure is adequate.
	Head speed too slow or too high	The blade/slide runs over the material without cutting it; increase or decrease head speed respectively.
	Cutting pressure to high	Reduce cutting pressure
	Insufficient coolant	Check the coolant level & clean piping & nozzles
<p>Broken blade</p> 	The non-homogenous material being cut	The material present may not be homogenous either on the surface, such as oxides or sand present or in sections, such as under-cooled inclusions. The variances in grain development cause the premature wearing of teeth & consequently, break as the result. Homogenise or clean these materials
	Head speed to high	Reduce head speed
	Teeth in contact with the material before commencing the cut	Always check the position of the blade before starting an initiating a new cut or job
	Insufficient coolant	Check the coolant level & clean piping & nozzles
	Excessive vibrations	Specimen vibrates in the vice; check that the vice clamps are position correctly & the clamping pressures are adequate

Brobo Group Warranty

- 1.1 The supplier warrants that all goods supplied by it, shall be free from defects in materials and workmanship for a period of twenty four (24) months from the date of delivery to the Customer. ("The Warranty Period"), on the following terms and conditions.
- 1.2 The Customer shall promptly provide written particulars to the supplier on becoming aware of any defect in the goods during the Warranty Period, and shall provide the Supplier with all necessary access, facilities and information to enable the Supplier to ascertain or verify the nature and the cause of the defect and to carry out its obligations under this warranty.
- 1.3 The Supplier's obligation under this warranty is limited to repairs of the defect goods and the Supplier is under no obligation to replace the goods or refund the value of the goods to the Customer.
- 1.4 If the goods are, in the opinion of the Supplier, not defective or if any defect is attributable to any one or more of the following circumstances then the Supplier is under no obligation whatsoever to the Customer:
- 1.4.1 The use of the goods for a purpose other than that for which they were intended to be used;
 - 1.4.2 The repair, modification or alteration of the goods by any person other than the Supplier;
 - 1.4.3 Where the defect has arisen due to misuse, neglect or accident, howsoever arising;
 - 1.4.4 Where the defect has arisen due to installation of the goods which were, in the reasonable opinion of the Supplier, incorrectly carried out
 - 1.4.5 Where the goods have not been correctly stored or maintained
 - 1.4.6 Where the defect has arisen due to normal wear and tear on the goods
- 1.5 The Supplier is under no obligation under this warranty where the Customer has failed to observe the terms of payment for the goods or any other obligation imposed by the terms and conditions of this warranty.
- 1.6 In the event that the Supplier is supplying goods, which have been manufactured by third parties, the Customer shall be entitled to the benefit of any Manufacturer's Warranty in respect of such goods. The Customer acknowledges that the Supplier accepts no responsibility whatsoever for any Manufacturer's Warranty or any claim howsoever arising from the use of the goods, whether singularly or in combination with other products.
- 1.7 The Supplier shall not be liable for any indirect or consequential losses or expenses suffered by the Customer, howsoever caused.
- 1.8 Except as specifically set out herein, or in writing by way of catalogue or pamphlet or otherwise provided by the Supplier to the Customer any term, representation, condition or warranty in respect of the quality, condition or description of the goods, whether implied by statute, common law, trade usage, custom or otherwise, is hereby expressly excluded.

This warranty is given by **Brobo Group Pty Ltd**, ABN: 42 098 264 316

Address: 8 Fowler Rd, Dandenong, VIC 3175



03 9794 8751



03 9794 8792



info@brobo.com.au

This warranty is provided in addition to other rights and remedies you have under law: Our goods come with guarantees which cannot be excluded under the Australian Consumer Law. You are entitled to replacement or refund for a major failure and to compensation for other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.