

250 PRADO BONNET STRUTS



STEP 1

Remove plastic molding from LH Side of engine bay. Repeat for RH side..



STEP 2

Remove centre bolt from LH side guard and set aside. Repeat for RH side.



250 PRADO BONNET STRUTS



STEP 3

Align the lower LH bracket as shown in picture and fasten to guard trim with OE bolt in original hole. Fasten a small bolt with wizlock nut in the other hole to secure bracket firmly. Repeat for RH side.



STEP 4

Remove the lower bolt from the LH bonnet hinge and fasten upper bracket to the hinge using the OE bolt. You will need to lift the bonnet up while doing so, help is recommended otherwise you can use a prop. OPTIONAL: Re paint the bolts to prevent rust and retain look. Repeat for RH side.



PART #: 82006

250 PRADO BONNET STRUTS



STEP 5

Remove the white clip from the LH plastic molding as shown in picture to allow for the extra bolt used in step 3. OPTIONAL: clip housing can be cut away for a flush mount when the molding is re-fitted. Repeat for RH side.



STEP 6

Re-fit the plastic moldings and test function of the struts.

STEP 7

Enjoy your new 250 Prado Bonnet Struts designed and made by ACOT500!

PROGRESS BEYOND DEVELOPMENT

+61 (0) 9295 6888 | sales@acot500.com | www.acot500.shop