




ToooAir

KWSA80K Quick Start Guide

Tooo Air Wide Area Platform

Tooo Air PTY LTD
Suite 1103, 1 Newland Street Bondi Junction, NSW 2022



KWSA80K Quick Start Guide



Thanks for choosing our product!

This Quick Start Guide is Only applicable to: KWSA80K.

Before using the product, please read the Quick Start Guide to fully benefit from the KWSA80K.

KWSA80K DIAGRAM



GETTING STARTED

1. Power ON Button
2. PTT Button
3. Volume Up / Down
4. Apps (applications) Tray
5. Speakers
6. Back Button
7. Home Button
8. Front Microphone
9. Recent Button
10. Display
11. Google Search Bar
12. Battery Level Indicator
13. Front Facing Camera
14. LED Notification
15. Receiver
16. Status Bar
17. SecureAudio Connector
18. Programmable Button
19. Emergency Button
20. Back Microphone
21. Torch/Flash Light
22. Rear Facing Camera
23. Battery Cover
24. Battery Cover Screw
25. USB-Type C


In the Box

- KWSA80K Device
- Battery
- Wall Charger
- USB-C Cable
- Screwdriver
- Quick Start Guide

INSTALLATION

Inserting the Battery

1. Unscrew cover
To open the battery cover, rotate the battery cover screws in a counter clockwise direction (as shown in the figure). Sometimes, the battery cover may be tight and some extra effort is required to open it. You can use the supplied screw driver tool to unscrew the screws.



2. Lift the cover
Lift the battery cover, to reveal the battery slot.



3. Insert battery
Insert the battery flush into the battery slot such that the three metallic contacts at the top of the battery are aligned with the metallic contacts within the battery compartment.



4. Close Cover
Close the battery cover. Rotate the battery cover screws in clockwise direction. You can use the supplied screwdriver to tighten the screws. Ensure not to over-tighten the screws. Make sure there is no gap between the battery cover and the body.



Inserting the SIM Card

Step 1


Use the included screwdriver to unscrew the battery cover screw on the back side.

Step 2

Remove battery cover and battery

Step 3

Open either SIM card tray, insert SIM card and lock SIM card tray into place.



Initial Phone Setup

Ensure that a valid SIM card is inserted in the board band Terminal. Press and hold Power On / Off key to power On the device. After the phone successfully registers with the network, the name of the service provider is displayed in the Status Bar. When powering on the phone for the first time, a Welcome Screen is displayed. To setup the phone, select Start and follow the instructions shown on the phone screen. After the initial phone setup is complete, the Home Screen is displayed.

Make a Call

From Home Screen, select the Phone application. Use the keypad or select a Contact. Select the green Phone icon to enable call.

Setup Wi-Fi

From the Home Screen, open Apps (applications) From the Apps Tray menu navigate to Settings > Wi-Fi > Toggle On > Choose the network you wish to connect to > Enter network password > Select connect

For the detailed instruction manual (USER MANUAL), refer to the following URL:

http://manual.kenwood.com/en_contents/search/keyword

IMPORTANT NOTICE**RECYCLING**

The crossed-out wheeled-bin symbol on your product, battery, literature, or packaging reminds you that all electrical and electronic products, batteries, and accumulators must be taken to separate collection at the end of their working life. Do not dispose of these products as unsorted municipal waste. Always return your used electronic products, batteries, and packaging materials to dedicated collection points. This way you help prevent uncontrolled waste disposal and promote the recycling of materials. More detailed information is available from the product retailer, local waste authorities or national producer responsibility organisations.

Note

After installation, please make sure that the USB port rubber plug are intact and closed for the device to be waterproof and dust-proof.

FURTHER SAFETY ADVICE

Please read and ensure you understand the following safety guidelines before you use the KWSA80K cellular device. These guidelines provide details to enable you to operate the device safely and conform to any legal requirements regarding the use of the cellular device.

- Do not use the cellular device at a refuelling point. Observe restrictions when using radio equipment at fuel depots, chemical plants or where blasting operations are in progress.
- Electrical interference may obstruct the use of the cellular device.
- Observe restrictions in hospitals and near medical equipment.
- Switch off the cellular device when in aircraft. Wireless devices can cause interference or danger to aircraft. In aircraft, the cellular device can be used in flight mode.
- Do not expose the cellular device to high temperatures (in excess of 55°C/ 131°F).
- Adhere to road safety laws. Do not hold/use a cellular device while you are driving; find a safe place to stop first. Use hands-free microphones or Bluetooth accessories while you are driving.
- Avoid using the cellular device in close proximity to personal medical devices, such as pacemakers and hearing aids.
- Use only KWSA80K approved charging equipment.
- Ensure that only qualified personnel install or repair the cellular device.
- Do not use accessory options not specified by KENWOOD.
- Do not place KWSA80K on unstable surfaces.
- Do not charge the battery pack or device when they are wet.
- Do not place the microphone cable around your neck while near machinery that may catch the cable.
- KWSA80K is water-proof and can be submerged to 2m for 30minutes.
- Ensure that the audio connector and the SIM slot are properly closed. This will prevent the deposit of water droplets on the connectors, when the cellular device is immersed in water.
- Water droplets may condense under the display cover if the cellular device is immersed in water with significant drop in temperature. This does not indicate water leakage. The droplets will disappear at room temperature.
- KWSA80K is dust-resistant, rugged and shock-resistant. However, it is not dust-proof or unbreakable if subjected to overwhelming impact. For best results and long product life, one should protect KWSA80K from salt water, dust and strong impacts.

WARRANTY

- Warranty period is 1 year from date of purchase
- For additional warranty information please check: <https://www.tooair.com.au/TermsConditions.aspx>

This product involves constant upgrading and/or improvement, our company reserves the right to change the specifications of software and/or hardware mentioned in this operating guide without any prior notice. The product specifications and information mentioned in the operating guide are for reference only.

Push-To-Talk Application

For the TooAir PTT App please refer to our application guide on our website:

<https://www.tooair.com.au/Resources.aspx>