

SMART WASTE SOLUTIONS AUSTRALIA: CP30

Step 1



Place bin under machine. If using extractor hose place safely in secure container.

Step 2



Ensure lever is in neutral position. Lift handle to open door.

Step 3



Place can/ filters inside machine, close the door and lower the handle to lock into position.

Step 4



Press the green button to start the cycle.

Step 5



Lower lever to the down position, the press will stay in the down position until the cycle is complete.

Step 6



Once the press is complete, return the lever to the neutral position and push green button to start cycle again.

Step 7



Raise lever to the up position.

Step 8



Once the cycle is complete, return the lever to the neutral position.

Step 9



Lift handle to open door.

Step 10



Slide can/ filters backwards to the waste disposal slit (to drop into bin) or remove can/ filters and place in bin.

MODEL: CP30

Safe Operating Procedure

Please remember to carefully read the complete "Manual for Operation" in the User Manual that was provided at installation before you start operating the Smart Equipment.

QR Code to Order Supplies



Find out more at:
www.SmartWaste.net.au



Thank you for helping to improve the environment by using a Smart Waste Solution.

Ph: 08 9248 8681 | Sales@smartwaste.net.au