

Under Mattress Sensor Mat- Corded RJ11 & JS63



AWAY FROM BODILY
FUNCTIONS

REDUCES INFECTION
RISK AND FACILITATE
INFECTION CONTROL

DOES NOT INTERFERE
WITH PRESSURE
RELIEF OF MATTRESS

MORE PATIENT
COMFORT

DOES NOT REQUIRE
TO BE REPOSITIONED
DAILY

LESS HANDLING, LESS
BREAKAGE

USE SOLVENT WIPES
TO DISINFECTANT &
CLEAN

PORTABLE

EASY TO MOVE FROM
ROOM TO ROOM

INTEGRATES TO MOST
NURSE CALL SYSTEMS

DURABLE & RELIABLE

LARGE SIZED
PRESSURE MAT
(840MM X 300MM)



Normally Open System - MED- B819-RJ11 (with RJ11) – requires a Monitor & Y-Lead
Normally Close System - MED- B819-JS63 (with 6.35mm Jack) – requires Interfacing Lead
Indigo Care provides a pressure sensitive Premium Under Mattress Sensor Mat that is designed to immediately alert staff should a resident leave their bed which is most useful to residents who are at risk of falling out of their bed, or those who require assistance in arising from the bed. The mat is place underneath the mattress, directly under the buttock area.

For a normally open call system, a monitor is required. Choose between our Anti-Tamper Deluxe Alarm Monitor (MED-TS1011A) or our Deluxe Voice Alert Monitor (MED-TS0893). For a normally open call system, a monitor is connected to the Under Mattress sensor mat (MED-B819-RJ11) and to the call point with a Y-cable. For a normally close call system, the bed mat (MED-B819-JS63) is connected directly to call point with an interfacing lead. Once the resident removes themselves form the bed, the sensor mat will activate the monitor's alarm/nurse call system and alert the staff. Set-up instructions are printed on the actual mat.

Eyelets at the corner of the pad are used to strap the mat to a fixed position if required.

ADVANTAGES OF UNDER MATTRESS SENSOR MAT:

- Away of bodily functions provides more comfort to the user
- Pressure relief function of mattress is not compromised
- Reduces infection risk, improves management & handling of infection control
- No need to reposition sensor mat multiple times a day
- Less handling means less breakage

Note: Under Mattress Sensor Mat may not work effectively with all the alternating air mattresses. Please check before purchase.

KEY SPECIFICATIONS:

- **Dimensions: 840mm X 300mm**
- **Connection: RJ11 for normally open – Requires a Monitor (Anti-Tamper or Voice Alert) and a Y Cable**
- **Connection: Jack 6.35mm plug for normally close – Requires an Interfacing Lead**
- **Electrical resistance < 500 Ohm**
- **White PVC, Thickness 0.20mm**
- **Warranty: 12 months**

PRODUCT ACCESSORIES:

- RJ11 requires Y Cable
- Jack 6.3 requires straight 6.35mm or 3.5mm cable
- Anti-Tamper Monitor or Voice Alert Monitor (4 X AA batteries-not included)
- 6V DC Adaptor (optional for Anti-Tamper Monitor only)

ORDER INFORMATION

Email your purchase orders to
sales@indigocare.com.au

INDIGO CARE
(Horizon Electronics Company, T/as)
2/93 Rushdale Street, Knoxfield, VIC, 3180
PH +61 3 9763-2988
www.horizone.com.au
ABN 36007302801