



WARNING TRIANGLE HOLDER

PART #: 65001

Mild Steel Galvanised Warning Triangle Holder, secures your warning triangle safely, to prevent it sliding around and breaking



BRACKET ISOLATOR SWITCH

PART #: 82307

Bracket Isolator Switch Fits 75910/75912 switch



BRACKET JUMP START RECEPTACLE

PART #: B-IMB2

Bracket jump start receptacle Heavy duty jump-start connector bracket for vehicles and equipment. 3mm mild steel powder coated black



BRACKET MINE LIGHT BAR MOUNTING KIT

PART #: B-MBUMK1-1 (No Spacer)

PART #: B-MBUMK1-2

PART #: B-MBUMK1-2P (Prado Spacer)

PART #: B-MBUMK1-3 (With Brass Hex Nut)

Bracket Mine Light Bar Mounting Kit Powder Coated Black Set (Left and Right) Channel Bolts spacers



BRACKET MINI LIGHT BAR MOUNTING KIT

PART #: B-SSL310ACB

Bracket Mini Light Bar Mounting Kit 2 x Mounting Feet Nuts, bolts, and washers included Fits SSL310ACB Mini Light Bar