

R2

Bluetooth RFID Reader

Accessories Guide



Standard

Adapter



PWR-R2-5V2A-CN



PWR-R2-5V2A-EU



PWR-R2-5V2A-UK



PWR-R2-5V2A-US

Adapter(CN/EU/UK/US), I/P: 100-240V, O/P: 5V2A, use with DC-R2/R6-USB cable

USB Cable



DC-BK-MicroUSB
1.0 meter Type-C cable

Battery



BTRY-R2-52MA
5200mAh Li-ion battery

Optional

Charging Cradles & Adapters



CRD-R2-MBC

Charging Cradle for battery, up to 2 slots, use with DCPWR-12V2A-XX



CN

UK

EU

US

DCPWR-12V2A-XX

R2 Extension Pole



RB-R2-ER

