

EarthLight ™

# Operation Guide

Mini Tower  
(Self Cleaning)



# OPERATION GUIDE

The all-in-one 40W solar light can operate in either of the following two modes

1. 100% brightness for 5 hours at dusk, then 20% until dawn.
2. 20% brightness then it will brighten to 100% once movement is detected by the motion sensor. Reduces back to 20% after 30 seconds of no movement

**From new out of the box they are set to mode 1.  
To set to mode 2 please follow the instructions below.**


Press and hold the RED button until the light turns on then release.

Press again and you will see the first RED light showing this means mode one.

Press again and the second RED lights should show this is now in mode 2.

The light is now switched on and in mode 2.

# TROUBLESHOOTING GUIDE



- 1
- 2
- 3
- 4

## TROUBLESHOOT GUIDE

<b>LED #1 &amp; #4 ON</b>	Sweeping function is faulty.
<b>LED #4 ON</b>	Drive power is faulty.
<b>LED #3 ON</b>	Main LED board is faulty.
<b>LED #2 ON</b>	Solar panel faulting.
<b>LED #1 ON</b>	Battery need replacing

## CHARGING INDICATION

<b>ALL FOUR INDICATOR LIGHTS ON</b>	Power is >80%
<b>THREE INDICATOR LIGHTS ON</b>	Power is 30%<60%
<b>TWO INDICATOR LIGHTS ON</b>	Power is <30%
<b>ONE INDICATOR LIGHT CONSTANTLY FLASHING</b>	Needs charging, Low Voltage indicator charge immediately.



# ILLUMINATE™ BETTER

