

Manual Supplement

Manual Title: TiX500, TiX501, TiX520, TiX560, TiX580 Users
Print Date: February 2020
Revision/Date: 2, 4/19

Supplement Issue: 1
Issue Date: 2/20
Page Count: 1

This supplement contains information necessary to ensure the accuracy of the above manual.

Change #1, 38

On page 47, after the **Clean the Product** section, add:

Lens Care

⚠ Caution

To prevent damage to the infrared lens:

- **Carefully clean the infrared lens. The lens has a delicate anti-reflective coating.**
- **Do not clean too vigorously as this can damage the anti-reflective coating.**
- **For lens care you will need a cleansing liquid such as a commercial lens cleaning liquid with alcohol, ethyl alcohol, or isopropyl alcohol and a lint-free cloth or tissue. A pressurized air can is used to remove loose particulates.**

To clean the lens:

1. Blow off particulates from the lens surface with pressurized air can or dry nitrogen-ion gun if available.
2. Soak the lint-free cloth in the alcohol liquid.
3. Squeeze the cloth to remove excess liquid or dab on dry cloth.
4. Wipe the lens surface in one circular motion and discard the cloth.
5. Use a new cloth with liquid if you need to repeat the procedure.