



CookTek Incogneeto Installation Guidelines



COOKTEK BY TURBOCHEF

Incogneeto[™] Installation Best Practices



Important Characteristics of Natural Stone

Stone is a natural material with random natural defects in any given piece. Cracking can occur due to these defects alone. Moreover, cracks can occur when pre-existing weak points are subjected to additional stresses or forces. Mechanical forces caused by poor support, joints in the support structure that shift, and weight distribution will cause excess stress on the stone. Heat differentials that cause one portion of the stone to try to expand while other portions try to remain fixed will cause excess stress. This localized heating can come from a number of sources:

- a. Heat lamps above the stone
- b. Heat generated by equipment below the stone
- c. Heat from hot items placed on top of the stone

In extensive testing conduction by CookTek, no natural stone was found to interfere with the performance of the wireless communications, or absorb excess heat from the electromagnetic induction waves associated with its Incogneeto $^{\text{TM}}$ and Magneeto $^{\text{TM}}$ equipment.

Design Considerations When Using Incogneeto™

- Any temperature gain that occurs inside the cabinet where an Incogneeto™ is mounted contributes to heating the stone. Keeping the inside of the cabinets as close to room temperature as possible will therefore reduce stress on the stone. Cabinets with poor or insufficient ventilation will increase the stress on the stone.
- Tensile strength of natural stone is proportional linear with thickness: 20 mm stone is ¼ thinner than 30 mm stone, so that resistance to cracking is also reduced by ¼. Applications with prolonged intensive use are better served with 30 mm stone above Incogneeto'" units.
- 30 mm thick natural stone dissipates heat much better than 20 mm, resulting in lower maximum temperatures. For prolonged intensive use application, thicker stone is more durable.
- The stone is not generally heated by the induction waves, but some heating will occur from radiation back from a hot pan. The stone around the portion that is heated from radiation provides the mechanical strength "buffer" to help prevent fractures. Allowing as much stone around the edge of the Incogneeto™ as possible will improve the strength of the whole system.

Best Practices Design Guidelines for Installation Under Natural Stone

It is recommended that natural stone over the Incogneeto[™] be 30 mm thick in high-use applications. Synthetic or "engineered stone" at 20 mm is acceptable over the Incogneeto'" in all applications. (Note: 20 mm tops in any material also require plywood substrate.) It is further recommended that cabinets be built with sufficient ventilation to keep the interior compartment as close to room temperature as possible.

At least 8 inches (203 mm) of additional stone surface should be allowed from the edge of the Incogneeto^m location to the final edge of any piece of stone. Extra care should be taken to not have mechanical seams in the cabinet support near the Incogneeto^m. Additionally, care should be taken when using heat lamps above Incogneeto units as they can damage the Magneeto trivets when a pan is not in place to absorb the energy.

If you have any questions, contact Customer Service at 1300 307 289 or email service@stoddart.com.au



Incogneeto Allowable Surface Materials



SURFACES THAT CAN BE USED

SYNTHETIC / ENGINEERED STONE*	
BRAND	MATERIAL COMPOSITION
Caesarstone	Quartz
Silestone	Quartz
Cambria	Quartz
Okite	Quartz
Santa Margherita	Quartz
Santa Margherita	Marble
Technistone	Quartz/Granite/Sand
Viatera	Quartz
Zodiaq	Quartz
Granite Transformations	Quartz/Granite/Sand
IceStone	Recycled Glass and Cement
Concetta	Gray Agatel Ice Quartz/ Amethyst
NATURAL STONE*	
	LITONE
Gra	nite
Ma	nite
Ma Soap	nite rble
Ma Soar Qua	nite rble ostone
Ma Soap Qua SI	nite rble ostone rtzite
Ma Soap Qua SI Lime	nite rble ostone rtzite ate
Ma Soap Qua Sl. Lime Qu *Engineered Granite	nite rble ostone rtzite ate sstone artz See Above
Ma Soap Qua Sl. Lime	nite rble estone rtzite ate estone artz

SURFACES THAT **CANNOT** BE USED

SOLID-SURFACE COUNTERTOPS ARE A BLEND OF ACRYLIC OR POLYESTER RESIN, POWEDERED FILLERS AND PIGMENTS, CAST INTO SLABS	
BRAND	MATERIAL COMPOSITION
DuPontCorian	Acrylic / Polyester Resins
LG HI-MACS	Acrylic / Polyester Resins
Wilsonart	Acrylic / Polyester Resins
Formica	Acrylic / Polyester Resins
Durat	Acrylic / Polyester Resins
Staron	Acrylic / Polyester Resins
Livingstone	Acrylic / Polyester Resins
Swanstone	Acrylic / Polyester Resins

Installation Instructions

Measure the countertop thickness where the unit will be installed (Figure 1). The top of the unit must be 38 to 42 mm from the top of the counter.



Figure 1: Measuring the Countertop Thickness

Mounting the Unit

The unit mounts in a square frame (supplied) underneath the counter. The frame is screwed into plywood, or narrow plywood strips (30 mm countertop thickness only), which are glued onto the stone, or stone's backing. No drilling or cutting of the stone is required.

20 mm Stone Countertop



Figure 2: IncogneetoTM Unit Mounted to 20 mm Countertop with Plywood Sheet

NOTE: 20 mm countertops must be installed with a plywood sheet.

30 mm Stone Countertop



Figure 3: $Incogneeto^{TM}$ Unit Mounted to 30 mm Countertop with Plywood Sheet



Figure 4: Incogneeto'MUnit Mounted to 30 mm Countertop with Two Plywood Strips



Incogneeto Installation Instructions



Installing the Unit

Attach the mounting frame to the wood sheet or strips with 1/2" wood screws. Make sure the frame is mounted square as shown in Figure 5. Next, snap the Incogneeto unit into place (Figure 6).

For assistance, call Stoddart on 1300 79 1954



Upper holes for strip mounting with 50mm total thickness only

Lower holes for sheet mounting

Figure5:Incogneetō FrameMountedOntoPlywoodSheet





Figure 6: Incogneetō Installed Under Countertop




Incogneeto Orientation Layout - Wall Buffet



Antenna pick up area 07 150 Min Distance between <u>Distance between Induction unit and top of counter must be 38 to 42mm</u> Induction Unit Fan Slot Fan Slot′ Incogneeto Orientation Layout - Island Buffet Induction Unit Fan Slot To run along the long side of bench Magneto Indicator Light To be opposite side to fan slot Timber Substrate Magneto Arial Stone Bench Top Induction Unit Doors or Removable Panels to Access Units Doors or Removable Panels to Access Units /Magneto 150 Min Distance between Clear Space 120 Min Doors or Removable Panels to Access Units

20 Timber

20 Stone Top



Brisbane

Sydney

Melbourne

Perth

Adelaide

1300 79 1954 www.stoddart.com.au

Manufactured or Imported & distributed exclusively by:

